BOSS®

zindagi aasan bana de

Crema

Rechargeable Frother

B-713

05 WATT



1 YEARS WARRANTY ON MOTOR

INSTRUCTION MANUAL

Please read all instructions carefully before using • T & C Apply*

Dear Customer,

Congratulations! Thank you for buying the BOSS Crema Rechargeable Frother!

The BOSS Crema Rechargeable Frother is carefully manufactured, tested and packaged to give you trouble-free performance. After all, it is from BOSS-a trusted name in home appliances for generations, with customers across the country.

Your BOSS Crema Rechargeable Frother will add convenience and a café-style touch to your favourite beverages.

We are sure you will love how easily it creates rich, creamy froth for coffee, hot chocolate, milkshakes and more. Its rechargeable design, Type-C charging and versatile whisk attachments make everyday mixing and frothing quick and effortless. To get the best performance from your BOSS Crema Rechargeable Frother, please read the instructions in this booklet carefully.

With Best Wishes,

BOSS®

B713 – BOSS Crema

Rechargeable Frother

Frother Main Unit	× 1
USB Cable	× 1
User Manual	× 1
Whisker Head	× 1
Beater Head	× 1

Whisker Head



Beater Head



TECHNICAL SPECIFICATIONS

Voltage	: 5V DC
Power	: 5W
Built-in Battery	: 800mAh

SAFETY NOTICES

- Please fully charge the product before you use it for the first time.
- Don't put main unit into water or any other liquid.
- Please remove it and straighten the metal rod, when the whisker head is shaken violently.
- Don't put any parts of this product into dishwasher for cleaning.
- This product should be kept out of reach of children. Close supervision is necessary when the appliance is being used with children around.

OPERATION INSTRUCTIONS

- **First Use:** Fully charge the main unit before initial use. The red light stays on during charging and the green light turns on when fully charged.
- **Speed Control:** Press once to start and switch speeds: 1st speed (low), 2nd speed (medium), 3rd speed (high).
- **Shutdown:** Press once to turn off when in 3rd speed. Long-press for 2 seconds to turn off when in 1st or 2nd speed.

MAINTENANCE AND STORAGE

- Please clean the whisker head after you use it, to avoid odour.
- Please clean main unit with damp rag.
- Don't disinfect the product with high temperature.
- Please make all parts dry before you store the product.
- Please charge and use it once every three months, when you don't use this product for a long time.