
BOSS®

Multifunctional USB Rechargeable Chopper

B-709



YEAR WARRANTY ON MOTOR

Product Features

- This product features in unique appearance, all body waterproof and wireless portable design.
- With the double electronic induction safety switch, users can control the grinding degree of food at will by pressing the switch.
- With the food grade processing bowl and Stainless Steel blades, the product is easy to clean and can be sterilized at high temperature, which is healthy and clean.
- 4. Detachable parts can be washed by water directly.

Instructions

- For the first use, please fully charge the main unit. After the main unit is fully charged, the blue indicator light is always being on. Then clean the main unit, blades and processing bowl.
- After the food is put into the processing bowl install the main unit along the two slots of the jar. When the main unit is installed, the blue indicator light flashes 5 Times. Then press the switch to process the food. Do not overload the jar, otherwise the blades may not rotate when it is started.





Place the blades with ingredients

Chopper will auto stop after 30 seconds. If the food is not so delicate you expected, continue to press the switch for processing. After finishing, remove the processing bowl attached from the main unit and pour out the food in the jar. Next, rinse it with water.





Install the main unit

Press Star

Cleaning

- Please clean the main unit, blades and processing bowl immediately after using the product.
- 2. The product can be cleaned directly with water or wiped with a soft wet cloth.
- 3. For more effective cleaning, you can apply a proper amount of detergent and clean it with a cleaning pad in warm water.4. The blades are very sharp. Do not touch the blades with your fingers to
- avoid personal injury. Clean the blades with very clean water so that you can see the blades when cleaning.
- Never use abrasive cleaning agents or aggressive liquids to clean the product.
- 6. Never sterilize any part of the product at high temperature.
- 7. Please dry or air dry all parts of the product after cleaning, and then reassemble and store the product.
- 8. If the product is not used for a long time, please charge the product within three months.

AUTHORISED SERVICE CENTRE

For Gujarat, Maharashtra & West Bengal: 9167681234

		Other Cities	
Ajmer	0145-2421785/2423650	Hyderabad	040-35841992 / 9347020195
	9982347880	Indore	0731-2534689 / 4969975
Banglore	080 41249187 / 41138318	Jaipur	0141-2622483
Belgaum	9986224792	Jodhpur	0291-2435266 / 9414129574
Bhilwara	01482-224586 / 9414112586	Kota	0744 - 2390532 / 9460056594
Bhopal	0755 - 4282097	Raipur	0771-2533284 / 9425510814
Delhi	011-23847057 / 9811206109	Rudrapur	9837049123
Gulbarga	9741734070 / 9480162059	Sambalpur	0663-2400042 / 9338025787
Hubli	0836-2284897 / 9845277503	Udaipur	0294-2422075

To Register Your Complaint, Simply Send Hi on Whatsapp



