# **B055**®



1500 WATT









**INSTRUCTION MANUAL** 

Dear Customer,


Thank you for choosing BOSS Brew Kettle, of which you are now the proud owner.

BOSS brings to you an Electric Kettle which is perfect for your daily home needs. Prepare hot water, instant tea etc., in a matter of minutes with BOSS Brew Kettle. With smart features like Concealed Heating Element, Wide Mouth for easy serving, Automatic Shut off, Ergonomic Handle, Elegant Body etc., this glamorously designed electric kettle is a must have accessory for your modern kitchen. 1500W power makes the boiling more efficient. Large capacity which suits for a whole family, the water comes to a full boil within 5-6 minutes and will be ready to use for tea, coffee, pasta, hot chocolate, oatmeal, instant soup and so on. This kettle has illuminated power indicator which glows when power is on and shuts when power is off. This makes BOSS Brew Kettle a perfect boiling partner for your kitchen!

Please read and follow all the instructions given in this user manual carefully, prior to using your BOSS Brew Kettle, to get the best result and trouble free operation.

With Best Wishes,

BOSS®



#### How to Use Your BOSS Brew Kettle

- Open the lid, pour in water, close the lid firmly.
   Caution: Do not fill the kettle with water above the maximum water level mark.
   If you do, hot water will overflow. Do not fill the kettle with water below the minimum water level mark.
   If you do, the kettle will not operate normally.
- Plug in, switch on the kettle. If the indicator lights up, the kettle is working. If
  the indicator does no light up, please push the switch button to power on and
  the kettle will begin to work with the indicator lighting up. After the water is
  boiled for a certain period of time, the power supply will be automatically cut
  off and the indicator will go off.
- 3. If you want to cut off power before the water is boiled, switch off the kettle or unplug the power cord.

#### **Important**

Please read the following instructions carefully before using the BOSS Brew Kettle.

- Remove all packing materials from the outside and inside of kettle.
- Keep the child away from the kettle when it is boiling.
- Never use the kettle without the lid on.
- This appliance should not be left unattended during use.
- Make sure the rated voltage printed on the rating label on the kettle is in conformity with local voltage before using.
- If an extension lead is required it must be earthed.
- Boil the water in kettle twice to clean the inside before use and pour out the boiled water.
- Do not touch the exterior as it gets hot or allow your hand to come in contact with hot steam from the spout or lid, particularly when refilling.
- To avoid the kettle overheating and lamp flashing, do not connect the power and press the switch button when the water is not pouring into the kettle.
- The unit is for boiling water only. Do not use it to heat other liquids or avoid damage.
- If the electrical source wire is broken, it must be replaced by manufacture or authorised service centre in order to keep safe.
- Never operate the appliance empty.
- This appliances is not intended for, use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Never immerse this appliance in water or other liquids. Use a damp cloth to clean the surface of appliance. Do not use aggressive or scourers.
- This appliance intended to be used in household and similar applications such
  as staff kitchen areas in shops, offices and other working environments farm
  houses by clients in hotels, motels and other residential type environments
  bed and breakfast type environments.

#### Care And Maintenance:

- 1. Always disconnect the power and leave to cool before cleaning.
- Clean the outside with a damp cloth. Do not use scouring power, nonscratch cream cleanser or any other cleaning products as they may discolor your kettle.
- 3. Please regularly clean out incrustation to ensure the normal working of the kettle.

  Do not scratch with metal material. Wash with diluted lemon extract.
- 4. Never immerse the kettle, cord and plug in water.
- 5. Store in cool & dry place.

Hubli

### **AUTHORISED SERVICE CENTRE**

### For Gujarat, Maharashtra & West Bengal: 9167681234 Other Cities

## Ajmer 0145-2421785/2423650 Hyderabad 040-35841992 / 9347020195 9982347880 Indore 0731-2534689 / 4969975 Banglore 080 41249187 / 41138318 Jaipur 0141-2622483

 Belgaum
 9986224792
 Jodhpur
 0291-2435266 / 9414129574

 Bhilwara
 01482-224586 / 9414112586
 Kota
 0744 - 2390532 / 9460056594

Bhopal 0755 - 4282097 Raipur 0771-2533284 / 9425510814

Delhi 011-23847057 / 9811206109 Rudrapur 9837049123

Gulbarga 9741734070 / 9480162059 Sambalpur 0663-2400042 / 9338025787

0836-2284897 / 9845277503 Udaipur 0294-2422075

To Register Your Complaint, Simply Send Hi on Whatsapp



